2.6 Deleting ENC/AVCS Chart AIO data

- 1) Start the Chart Portfolio.
- 2) Click [Sort] [S-57] from the "Chart Portfolio" menu.
 Select [Sort] [S-63] in that order when importing S-63 chart.
 Select [Sort] [AIO] in that order when importing AIO data.
 ※ Excluding JMA-900B



3) Click the "[S-57] System Chart" tab to display the imported S-57 charts.



4) Click one folder.



5) Select from the displayed charts by the mouse cursor. Multiple charts can be selected by moving the cursor while holding down the mouse left button.

Ecdis Chart Po	rtfolio	D							
Chart Sort	Edit	View	Tool Ve	rsion					
Auto Detect	Import		STOP	Inform	D				
[S-57] Source C	hart [S-57] System	Chart			Selected	charts	will	be
🗀 S57	-	Chart	Scale	UpNo.	Last Upd	highlighte	d		
📗 🗠 😋 AR		AR201130	2:gene	2.5	09/03/201	ingingine	u.		
📕 🧰 AU		AR201140	2:gene	1.4	09/03/201	2			
BE		AR202100	2:gene	1.2	09/03/201	2 Y	es		
BH		AR203100	2:gene	1.0	09/03/201	2 Y	es 🔰		
BR		AR301150	3:coas	1.1	09/03/201	2 Y	es		
		AR302120	3:coas	2.4	09/03/201	2 Y	es		
		AR302130	3:coas	1.0	09/03/201	2 Y	es		
		AR302160	3:coas	1.0	09/03/201	2 Y	es		

6) Click [Edit] – [Delete] from the "Chart Portfolio" menu.

Ecdis Chart Portfolio					
Chart Sort	Edit	View	Te		
	Sele	ect All			
Auto Detect In	Del	ete			

7) Click the [OK] button.



The folder itself will also be deleted when all the charts in the folder are deleted. Then, the next folder is automatically selected and the charts in the next folder will be listed.

Ecdis Chart Pe	ortfolio	D					
Chart Sort	Edit	View	Tool Ve	rsion			
Auto Detect) /Update	STOP Abort	B Information		Log	
[S-57] Source ([S-57] Source Chart [S-57] System Chart						
🗀 S57	-	Chart	Scale	UpNo.	Last Update	Accepted	
🛛 🗠 😋 AU		AU130060	1:over	1.1	09/03/2012	Yes	
📗 🚾 BE		AU130090	1:over	3.6	09/03/2012	Yes	
📗 🖳 BH		AU130120	1:over	9.3	09/03/2012	Yes	
II 🔤 BR		AU130150	1:over	8.0	09/03/2012	Yes	
C1		AU160060	1:over	2.2	09/03/2012	Yes	
		AU160090	1:over	2.3	09/03/2012	Yes	
		AU160120	1:over	2.4	09/03/2012	Yes	
		AU160150	1:over	5.3	09/03/2012	Yes	

8) Repeat the above procedure from (5) to (8) to delete the unnecessary S-57 charts.

When all the imported S-57 charts are deleted, no charts will be listed on "[S-57] System Chart."

9) Click the [Exit] button.



10) Click the [OK] button.



2.7 Deleting Cell Permit (Only S-63)

Note:

• Please delete previous Cell permit as following procedures after changing in the contract detail.

• Deleting Cell permit clears all Cell permits of each data server (PRIMAR, UKHO (AVCS),

Hydrographic and Oceanographic Department of Japan Coast Guard, etc.).

• Imported charts are still able to show after deleting Cell permit.

- 1) Start the Chart Portfolio.
- 2) Select [Tool] [Option] in that order. The "Option" panel opens.

Ecdis Chart Po	ortfolio				
Chart Sor	t Edit	dit View Tool Version			
		0 pti	on		
🔏 Auto Detect	نے۔ Import/Update		Technical Tool		
[S-57] Sourc	e Chart [Mair	ntenance	V,	

 Left-click the [S-63/AVCS] tab, and then, the [Select of Certificate...] button. The "Option" dialog box opens.

Option	
S-57	S-63/AVCS ARCS Advanced
_ SA	. Certificate
	Import of Certificate
	Select of Certificate
Ce	ll Permit
1	Import Cell Permit
	Delete Cell Permit
Y C	ou have 9928 chart(s) license.) chart(s) license has(have) expired.
Usi	er Permit
51	6F8A5FCA37AE2437D727283933
	OK Cancel

4) Left-click the [Yes] button to delete the Cell permit.

